

How to PROFESSIONALLY heat transfer your Name, Number and Logos onto your Jersey.

All applications must be performed on a Professional Heat press machine.
You CAN NOT use a household Iron

- 1.** Pre Heat your jersey. Do this by putting your jersey over the platen and placing a Teflon sheet on the area that is going to receive the heat transfer. Again, your professional heat presser will have this Teflon sheet. Pre Heat for 15-17 seconds at 310 degrees
- 2.** Peel the transfer from the paper backing, by peeling an edge of the clear transfer tape-The transfer is meant to stick to the clear transfer tape. Position your name, number or logos onto your jersey. (In your desired locations)
You will be looking at your name, number or logos through the clear cover (known as transfer tape)
- 3.** Take the Teflon sheet you used to pre heat your jersey and place it on top of the clear cover (transfer tape)
Using medium pressure and a temperature of 310 degrees, press your image for 15-17 seconds.
- 4.** Remove Teflon sheet
LET COOL before removing the clear cover (Transfer tape) from your image.

Proper laundering of your jerseys

Do not use fabric softer in your wash or dryer
Wash cold, Hang dry

