



Jersey/Heat Transfer Instructions

How to PROFESSIONALLY heat transfer your Name, Number and Logos onto your Jersey.

All applications must be performed on a Industrial/Professional Heat Press Machine.

You CANNOT use a household Iron

For best results - Dampen a cloth or rag with rubbing alcohol and wipe the area of the jersey where you plan to apply the iron on (jersey print). Allow it to dry for 30 minutes. This will allow better adhesion to the garment.
ANY QUESTIONS Call 815-784-4000

1. Pre Heat your jersey. Do this by putting your jersey over the platen and placing a Teflon sheet on the area of the jersey that is going to receive the heat transfer. Again, your professional heat presser will have this Teflon sheet. Pre Heat for 10 seconds at 275 degrees
2. Remove the paper backing from your Custom Jersey Print iron on. The Jersey print transfer is meant to stick to the clear cover known as the transfer tape.
3. Position your name, number or logos onto your jersey. In your desired locations. You will be looking at your name, number or logos through the clear transfer tape.
4. Take the Teflon sheet you used to pre heat your jersey and place it on top of the clear transfer tape.
5. Using Hard even pressure and a temperature of 275 degrees, press your image for 20-25 seconds.
6. Remove Teflon sheet. While still warm, slowly peel away the clear transfer tape from your image.
7. Original jersey color and design may bleed through your name and number.

Proper laundering of your jerseys

Do not use fabric softer in your wash or dryer
Wash cold inside out , Hang dry.

