

Seat Cover Installation

Tools needed:

1/4" Long x 1/2" Wide galvanized or stainless staples.

(Anything longer will go through the foam and you will feel it through the seat.)

Staple Gun

Flathead screwdriver

Needle nose pliers

Scissors



1 - Remove old cover and staples.



2 - New Cover: Slip the front of the nose on first.
Add a few staples in the nose area.



3 - Stretch the cover to the back. Add a few staples in the rear area.



4 - Tack down the middle of the sides next.



5 - Trim the cover around the seat mount area.



6 - Finish the front area.



7 - Finish the back area.



8 - Finish both sides.

